






04 003 03 00

R37..



R37F..



(→ 14)	DR63..	DT71D	DT80..	DT90..	DV100M	DV100L					
AC	132	145	145	197	197	197					
AD	105	122	122	154	166	166					
ADS	105	127	127	161	166	166					
L	392	407	457	477	529	559					
LS	447	470	520	562	614	644					
LB	191	206	256	276	328	358					
LBS	246	269	319	361	413	443					