




04 031 03 00

RX97..

(→ 14)	DV132S	DV132M	DV132ML	DV160M	DV160L	DV180..	DV200..				
AC	221	275	275	275	331	331	394				
AD	179	230	230	230	258	258	285				
ADS	182	230	230	230	258	258	285				
L	696	718	778	778	825	897	945				
LS	776	830	890	890	981	1053	1101				
LB	380	402	462	462	509	581	629				
LBS	460	514	574	574	665	737	785				