




05 011 03 00

S77..

(→ 14)	DT80..	DT90..	DV100M	DV100L	DV112M	DV132S	DV132M	DV132ML			
AC	145	197	197	197	221	221	275	275			
AD	122	154	166	166	179	179	230	230			
ADS	127	161	166	166	182	182	230	230			
L	530	548	598	628	632	677	699	759			
LS	594	633	683	713	712	757	811	871			
LB	243	261	311	341	345	390	412	472			
LBS	307	346	396	426	425	470	524	584			