


SF97..


05 020 03 00



6

SAF97..

SHF97..



(→ 14)	DT90..	DV100M	DV100L	DV112M	DV132S	DV132M	DV132ML	DV160M	DV160L	DV180..
AC	197	197	197	221	221	275	275	275	331	331
AD	154	166	166	179	179	230	230	230	258	258
ADS	161	166	166	182	182	230	230	230	258	258
L	671	721	751	755	800	822	882	882	929	1001
LS	756	806	836	835	880	934	994	994	1085	1157
LB	251	301	331	335	380	402	462	462	509	581
LBS	336	386	416	415	460	514	574	574	665	737